

3400 W. Segerstrom Avenue, Santa Ana, California 92704 or [www.behr.com](http://www.behr.com)



**PREMIUM  
WEATHERPROOFING  
SEMI-TRANSPARENT DECK,  
FENCE & SIDING STAIN  
No. 5-77 DEEP TINT BASE**

### RECOMMENDED USES:

*Exterior, properly prepared, unsealed wood surfaces such as: Decks, Railings, Shakes, Shingles, Siding, Roofs, Fences and Furniture.*

**AVAILABLE IN: Gallon & Five Gallon**

### COLORS

No. 5-77 Deep Tint Base

### TINT BASE / MAX. TINT\*

No. 5-77-120 oz.

Deep Tint Base-8 oz.

### FINISH

N/A

### COVERAGE RATE

250-300 sq. ft. per gallon (23-28 m<sup>2</sup>) depending on porosity of surface.

### DRYING TIME

@77°F & 50% humidity\*

\*Longer dry time required in cooler temperatures and in higher humidity.

Light Foot Traffic: 24-48 Hours  
Reposition Furniture: 72 Hours

### PRIMERS

N/A

### COMPOSITION

**Vehicle/Active Ingredient:**

Acrylic/Alkyd core-shell

**Percent Solids By Volume:**

23.5-24.5 %

**Percent Solids By Weight:**

26-27%

**Weight Per Gallon:**

8.5-8.7 lbs.

### VOC

77 gm/l Material (Including Water)

244 gm/l Coating (Excludes Water)

### Flashpoint

N/A

### MSDS

Available @ [www.behr.com](http://www.behr.com)

Or 1-800-854-0133 Ext. 2

### Clean Up

Soap & Water. Recycle or dispose of paint call 1-800-CLEANUP (U.S.A. only) [www.earth911.org](http://www.earth911.org)

### SURFACE PREPARATION

**For All Uncoated Wood:** Test the woods condition by placing cloth duct tape directly on random areas of the uncoated wood and press firmly. Pull the tape off quickly. If any wood fibers are pulled on to the tape, the wood surface is not sound and you need to follow all of the steps listed for coated wood. If no wood fibers are pulled on to the tape, proceed to step two. Remove algae, fungus, grime, and mildew stains with BEHR® No. 62 Multi-Surface Cleaner & Mildew Stain Remover. Rinse. Follow with BEHR® No. 63 Wood Cleaner Brightener Conditioner to clean, open wood grain, neutralize and rejuvenate the natural color of the wood. Rinse thoroughly. (Continued next Column)

### APPLICATION TOOLS

**Airless Spray:** Filter: 60 mesh Tip: .015

**Conventional Spray:** See manufactures Recommendations.

**Pump Sprayer:** A high quality pump sprayer with a variable tip

**Brush:** Nylon/Polyester blend or Pad Applicator

**Roller:** 3/8" Nap. Rough surface only.

**Thinner:** Do Not Thin.

### SURFACE PREPARATION CONT'D

For All Coated Wood: Remove loose wood fibers and/or deteriorated finishes with BEHR® No. 64 15 Minute Quik-Fix™ Deck Finish Remover & Wood Resurfacer. Rinse. Remove algae, fungus, grime, and mildew stains with BEHR® No. 62 Multi-Surface Cleaner & Mildew Stain Remover. Rinse. Follow with BEHR® No. 63 Wood Cleaner Brightener Conditioner to clean, open wood grain, neutralize and rejuvenate the natural color of the wood. Rinse thoroughly.

### APPLICATION

Do not use if temperature is below 40°F (4.5°C), above 90°F (32°C), or if rain is expected within 24 hours. The wood surface may be coated when damp/dry. Wipe any standing water off the surface prior to applying the finish. When working with more than one container of the same color, intermix to ensure color uniformity. • Stir stain before and occasionally during application. Test product for penetration and color on a small hidden area before proceeding. If a pump sprayer is used, work in small sections lightly saturating the surface and back-brush/roll immediately to remove excess and evenly distribute the finish. Maintain a wet edge when applying. Always back-brush during all application methods. Apply product end-to-end or to board lengths to prevent lap marks. For optimum performance, coat all six sides of wood. One coat is recommended.

This information is believed to be reliable; however Behr Process Corporation makes no warranty, guarantee, or representation and assumes no liability as to the absolute correctness or sufficiency of the specifications.

**To Consult with a Technical Service Representative call  
1-800-854-0133 Ext. 2**

3400 W. Segerstrom Avenue, Santa Ana, California 92704 or [www.behr.com](http://www.behr.com)



**PREMIUM  
WEATHERPROOFING  
SEMI-TRANSPARENT DECK,  
FENCE & SIDING STAIN No.  
5-88 WHITE TINT BASE**

**RECOMMENDED USES:**

*Exterior, properly prepared, unsealed wood surfaces such as: Decks, Railings, Shakes, Shingles, Siding, Roofs, Fences and Furniture.*

**AVAILABLE IN:** Gallon & Five Gallon

**COLORS**

No. 5-88 White Tint Base

**TINT BASE / MAX. TINT\***

No. 5-88-124 oz.

White Tint Base-4 oz.

**FINISH**

N/A

**COVERAGE RATE**

250-300 sq. ft. per gallon (23-28 m<sup>2</sup>) depending on porosity of surface.

**DRYING TIME**

@77°F & 50% humidity\*

\*Longer dry time required in cooler temperatures and in higher humidity.

Light Foot Traffic: 24-48 Hours

Reposition Furniture: 72 Hours

**PRIMERS**

N/A

**COMPOSITION**

**Vehicle/Active Ingredient:**

Acrylic/Alkyd core-shell

**Percent Solids By Volume:**

24-25%

**Percent Solids By Weight:**

27.5-28.5 %

**Weight Per Gallon:**

8.7-8.9 lbs.

**VOC**

80 gm/l Material (Includes Water)

244 gm/l Coating (Excludes Water)

**Flashpoint**

N/A

**MSDS**

Available @ [www.behr.com](http://www.behr.com)

Or 1-800-854-0133 Ext. 2

**Clean Up**

Soap & Water. Recycle or dispose of paint call 1-800-CLEANUP (U.S.A. only) [www.earth911.org](http://www.earth911.org)

**SURFACE PREPARATION**

**For All Uncoated Wood:** Test the woods condition by placing cloth duct tape directly on random areas of the uncoated wood and press firmly. Pull the tape off quickly. If any wood fibers are pulled on to the tape, the wood surface is not sound and you need to follow all of the steps listed for coated wood. If no wood fibers are pulled on to the tape, proceed to step two. Remove algae, fungus, grime, and mildew stains with BEHR® No. 62 Multi-Surface Cleaner & Mildew Stain Remover. Rinse. Follow with BEHR® No. 63 Wood Cleaner Brightener Conditioner to clean, open wood grain, neutralize and rejuvenate the natural color of the wood. Rinse thoroughly. (continued next column)

**APPLICATION TOOLS**

**Airless Spray:** Filter: 60 mesh Tip: .015

**Conventional Spray:** See manufactures Recommendations.

**Pump Sprayer:** A high quality pump sprayer with a variable tip

**Brush:** Nylon/Polyester blend or Pad Applicator

**Roller:** 3/8" Nap. Rough surface only.

**Thinner:** Do Not Thin.

**SURFACE PREPARATION CONT'D**

**For All Coated Wood:** Remove loose wood fibers and/or deteriorated finishes with BEHR® No. 64 15 Minute Quick-Fix™ Deck Finish Remover & Wood Resurfacer. Rinse. Remove algae, fungus, grime, and mildew stains with BEHR® No. 62 Multi-Surface Cleaner & Mildew Stain Remover. Rinse. Follow with BEHR® No. 63 Wood Cleaner Brightener Conditioner to clean, open wood grain, neutralize and rejuvenate the natural color of the wood. Rinse thoroughly.

**APPLICATION**

Do not use if temperature is below 40°F (4.5°C), above 90°F (32°C), or if rain is expected within 24 hours. The wood surface may be coated when damp/dry. Wipe any standing water off the surface prior to applying the finish. When working with more than one container of the same color, intermix to ensure color uniformity. • Stir stain before and occasionally during application. Test product for penetration and color on a small hidden area before proceeding. If a pump sprayer is used, work in small sections lightly saturating the surface and back-brush/roll immediately to remove excess and evenly distribute the finish. Maintain a wet edge when applying. Always back-brush during all application methods. Apply product end-to-end or to board lengths to prevent lap marks. For optimum performance, coat all six sides of wood. One coat is recommended. Spread rate is approximately 250-300 sq. ft. per gallon (23-28 m<sup>2</sup>).

This information is believed to be reliable; however Behr Process Corporation makes no warranty, guarantee, or representation and assumes no liability as to the absolute correctness or sufficiency of the specifications.

**To Consult with a Technical Service Representative call 1-800-854-0133 Ext. 2**

3400 W. Segerstrom Avenue, Santa Ana, California 92704 or [www.behr.com](http://www.behr.com)



**PREMIUM  
WEATHERPROOFING  
SEMI-TRANSPARENT DECK,  
FENCE & SIDING STAIN  
No. 5-533 CEDAR NATURALTONE**

### RECOMMENDED USES:

*Exterior, properly prepared, unsealed wood surfaces such as: Decks, Railings, Shakes, Shingles, Siding, Roofs, Fences and Furniture.*

**AVAILABLE IN: Gallon Only**

### COLORS

No. 5-533 Cedar Naturaltone

### TINT BASE / MAX. TINT\*

No. 5-533-128 oz.

Pre-Mixed-Stock Color

### FINISH

N/A

### COVERAGE RATE

250-300 sq. ft. per gallon (23-28 m<sup>2</sup>) depending on porosity of surface.

### DRYING TIME

@77°F & 50% humidity\*

\*Longer dry time required in cooler temperatures and in higher humidity.

Light Foot Traffic: 24-48 Hours  
Reposition Furniture: 72 Hours

### PRIMERS

N/A

### COMPOSITION

**Vehicle/Active Ingredient:**

Acrylic/Alkyd core-shell

**Percent Solids By Volume:**

23.5-25 %

**Percent Solids By Weight:**

26-28.5%

**Weight Per Gallon:**

8.5-8.7 lbs.

### VOC

78 gm/l Material (Including Water)

243 gm/l Coating (Excludes Water)

### Flashpoint

N/A

### MSDS

Available @ [www.behr.com](http://www.behr.com)

Or 1-800-854-0133 Ext. 2

### Clean Up

Soap & Water. Recycle or dispose of paint call 1-800-CLEANUP (U.S.A. only) [www.earth911.org](http://www.earth911.org)

### SURFACE PREPARATION

**For All Uncoated Wood:** Test the woods condition by placing cloth duct tape directly on random areas of the uncoated wood and press firmly. Pull the tape off quickly. If any wood fibers are pulled on to the tape, the wood surface is not sound and you need to follow all of the steps listed for coated wood. If no wood fibers are pulled on to the tape, proceed to step two. Remove algae, fungus, grime, and mildew stains with BEHR® No. 62 Multi-Surface Cleaner & Mildew Stain Remover. Rinse. Follow with BEHR® No. 63 Wood Cleaner Brightener Conditioner to clean, open wood grain, neutralize and rejuvenate the natural color of the wood. Rinse thoroughly. (Continued next Column)

### APPLICATION TOOLS

**Airless Spray:** Filter: 60 mesh Tip: .015

**Conventional Spray:** See manufactures Recommendations.

**Pump Sprayer:** A high quality pump sprayer with a variable tip

**Brush:** Nylon/Polyester blend or Pad Applicator

**Roller:** 3/8" Nap. Rough surface only.

**Thinner:** Do Not Thin.

### SURFACE PREPARATION CONT'D

**For All Coated Wood:** Remove loose wood fibers and/or deteriorated finishes with BEHR® No. 64 15 Minute Quick-Fix™ Deck Finish Remover & Wood Resurfacer. Rinse. Remove algae, fungus, grime, and mildew stains with BEHR® No. 62 Multi-Surface Cleaner & Mildew Stain Remover. Rinse. Follow with BEHR® No. 63 Wood Cleaner Brightener Conditioner to clean, open wood grain, neutralize and rejuvenate the natural color of the wood. Rinse thoroughly.

### APPLICATION

Do not use if temperature is below 40°F (4.5°C), above 90°F (32°C), or if rain is expected within 24 hours. The wood surface may be coated when damp/dry. Wipe any standing water off the surface prior to applying the finish. When working with more than one container of the same color, intermix to ensure color uniformity. • Stir stain before and occasionally during application. Test product for penetration and color on a small hidden area before proceeding. If a pump sprayer is used, work in small sections lightly saturating the surface and back-brush/roll immediately to remove excess and evenly distribute the finish. Maintain a wet edge when applying. Always back-brush during all application methods. Apply product end-to-end or to board lengths to prevent lap marks. For optimum performance, coat all six sides of wood. One coat is recommended.

This information is believed to be reliable; however Behr Process Corporation makes no warranty, guarantee, or representation and assumes no liability as to the absolute correctness or sufficiency of the specifications.

**To Consult with a Technical Service Representative call  
1-800-854-0133 Ext. 2**