



## BELLAGIO FAUX

### NO. 725 INTERIOR DECORATIVE FINISH

#### PRODUCT INFORMATION

BEHR PREMIUM PLUS® Interior Decorative Finish NO. 725 is a Bellagio faux designed for interior surfaces and offers a beautiful finish with a European fresco look. Creates depth and a unique washed look. Easy to apply and touch up. Durable washable finish. Apply over a flat enamel base color.

#### RECOMMENDED USES:

Use on previously painted or primed interior surfaces. Ideal for family rooms, living rooms, dining rooms, bedrooms, hallways and ceilings.



#### PRODUCT SPECIFICATIONS:

##### Tint Bases/Max Tint Load:

NO. 725 Untinted Base 128 oz / Do Not Tint

**Sheen:** Will vary depending on application technique

**Vehicle Type:** 100% Acrylic

**\*Weight per Gallon:** 9.3 lbs at +/- 2%

##### \*% Solids:

By Volume: 22% at +/- 2%

By Weight: 28% at +/- 2%

**VOC:** <50 (g/l), meets the requirements for LEED credits, as the product meets VOC limits as established by Green Seal Standards GS-11, First Edition, May 20, 1993.

**Flash Point:** Not Applicable

**\*Coverage:** 250-350 SFPG, depending on application method and substrate porosity.

#### RECOMMENDED PRIMER / SYSTEMS:

##### PROPERLY PREPARED NEW SURFACES:

##### Gypsum Wallboard:

- BEHR PREMIUM PLUS® Interior No. 75 Enamel Undercoater primer & Sealer

##### Plaster:

- BEHR PREMIUM PLUS® Interior No. 75 Enamel Undercoater Primer & Sealer

##### Wood:

- BEHR PREMIUM PLUS® Interior/Exterior No. 434 Oil-Based Primer & Sealer
- BEHR PREMIUM PLUS® Interior No. 75 Enamel Undercoater Primer & Sealer

##### Tannin/Stainblocking:

- BEHR PREMIUM PLUS® Interior/Exterior No. 434 Oil-Based Primer & Sealer
- BEHR PREMIUM PLUS® Interior No. 75 Enamel Undercoater Primer & Sealer

##### Masonry:

- BEHR PREMIUM PLUS® Interior No. 75 Enamel Undercoater Primer & Sealer

##### Galvanized Metal, Metal & Aluminum:

- BEHR PREMIUM PLUS® Interior No. 75 Enamel Undercoater Primer & Sealer

##### PREVIOUSLY PAINTED SURFACES:

- BEHR PREMIUM PLUS® Interior/Exterior No. 434 Oil-Based Primer & Sealer
- BEHR PREMIUM PLUS® Interior No. 75 Enamel Undercoater Primer & Sealer

#### APPLICATION:

**Note:** Different applicators will provide different finishes and looks. Test product's application by making samples before beginning project.

**Brush:** Nylon/polyester, Whisk Broom, Sponge, Putty Knife or Trowel

**Roller:** Looped Roller, Short Nap Roller

**Airless Spray:** Not recommended

**Tip:** N/A

**Filter:** N/A

† **Dry Time:** @ 77° & 50% RH

Longer dry time may be required in cooler temperatures and higher humidity.

† To Touch: 15-20 Minutes

† To Recoat: 4 hours

† To Repaint: 24 - 48 Hours

† Full Cure: 1 week

#### CAUTIONS/LIMITATIONS:

- Protect from freezing.
- Do not use on floors.
- For best results, apply at temperatures between 50°F - 90°F. Temperatures above 90°F may affect the application such as drying to fast. Avoid painting in direct sun. NOTE: If the surface is hot to the touch it should be considered to hot to apply this coating.
- Allow two weeks before washing or cleaning for full cure.
- Shelf life under normal conditions is two years unopened.

#### CLEAN UP:

Clean all tools and equipment with clean water. For disposal of empty containers and unused product, contact your household refuse collection service.

\*This information is provided "as is" and no representations or warranties, either expressed or implied, or merchantability, fitness for a particular purpose or of any other nature are made with respect to this information or to any product referred to in this information.





## BELLAGIO FAUX

### NO. 725 INTERIOR DECORATIVE FINISH

† **WARNING!** If you scrape sand or remove old paint, you may release lead dust. **LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE.**

Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to [www.epa.gov/lead](http://www.epa.gov/lead). **WARNING!** This product contains chemicals known to the state of California to cause cancer and birth defects or other reproductive harm. **WARNING!** Sanding or scraping pressure treated lumber may be hazardous; wear appropriate protection.

#### SURFACE PREPARATION:

All surfaces must be clean, free of dust, chalk, oil, grease, wax, polish, mold and mildew stains, loose and peeling paint, rust and all other foreign substances.

**Mildew:** All surfaces must be clean of mold and mildew stains and dirt prior to coating.

**Interior:** Use one part BEHR® Premium Mildew Stain Remover No. 62 to three parts water (1:3 dilution).

**DO NOT USE FULL STRENGTH.** Avoid contact with clothing, carpet and fabrics. Apply using a clean cloth or sponge. Thoroughly rinse the surface with fresh water. Prolonged exposure on painted surfaces may damage finish.

**New Drywall:** All drywall surfaces should be sufficiently sanded smooth. Remove any remaining drywall dust prior to priming. Allow all drywall compounds to be completely dry prior to coating. **Previously Painted Gypsum Board/Drywall:** Remove all loose and peeling paint and all other foreign substances. Clean any dirt and grease by scrubbing the surface with a detergent and water solution, followed by a thorough rinsing with clean water. Set nails and fill holes, scratches, and gouges with the appropriate spackling material and let dry completely and sand smooth. Remove all dust with a wiping cloth. Fill all gaps with a 100% acrylic, siliconized, paintable caulking, and allow to completely dry prior to coating. **Glossy Surfaces:** For maximum adhesion, sand the surface thoroughly before coating. **New Wood:** Remove mill glaze with sandpaper. Set nails and fill holes, scratches, and gouges with the appropriate wood filler and

let dry completely. Remove all dust with a wiping cloth. Fill all gaps with a 100% acrylic, siliconized, paintable caulking, and allow to completely dry prior to coating.

**Previously Painted Wood:** Remove all loose and peeling paint and all other foreign substances. Clean any dirt and grease by scrubbing the surface with a detergent and water solution, followed by a thorough rinsing with clean water. Set nails and fill holes, scratches, and gouges with the appropriate wood filler and let dry completely. Remove all dust with a tack or wiping cloth. Fill all gaps with a 100% acrylic, siliconized, paintable caulking, and allow to completely dry prior to coating. **Glossy Surfaces:** For maximum adhesion, sand the surface thoroughly before coating.

**Wood:** **WARNING!** Sanding or scraping pressure treated lumber may be hazardous; wear appropriate protection.

**New Plaster:** New plaster should be thoroughly dried out and cured for a minimum of 30 days before painting. When cured, clean using a mixed solution of one part vinegar and one part water to remove efflorescence and neutralize. **Previously Painted Plaster:** Remove all loose and peeling paint and all other foreign substances. Clean any dirt and grease by scrubbing the surface with a detergent and water solution, followed by a thorough rinsing with clean water. Set nails and fill holes, scratches, and gouges with the appropriate spackling material and let dry completely and sand smooth. Remove all dust with a tack or wiping cloth. Fill all gaps with a 100% acrylic, siliconized, paintable caulking, and allow to completely dry prior to coating. **Glossy Surfaces:** For maximum adhesion, sand the surface thoroughly before coating.

**Stainblocking:** After priming, test for stain bleed-through by applying the topcoat to a small section. If the stain bleeds through the topcoat, apply a second coat of primer and test again before top-coating the entire area. If bleeding continues, a longer dry time of the primer may be needed before top-coating.

**Masonry:** All masonry surfaces must be cured at least 30 days before painting. The pH must be 10.0 or lower prior to coating. Smooth masonry may require an adequate profile for adhesion. For all other smooth trowel concrete, create a profile using BEHR® Concrete & Masonry Surface Prep No. 991 or with mechanical means. Remove loose aggregate and debris using BEHR® Concrete & Masonry Cleaner/Degreaser No. 990. Scrub vigorously into the surface with a plastic brush, broom or power washer. **Rinse thoroughly with water and allow to dry**

\*This information is provided "as is" and no representations or warranties, either expressed or implied, or merchantability, fitness for a particular purpose or of any other nature are made with respect to this information or to any product referred to in this information.

For MSDS or to consult with a BEHR® Certified Coatings Professional, call 1-800-854-0133 Ext. 2 (U.S.A. only). ©2010 BEHR PROCESS CORPORATION, Santa Ana, CA 92704 U.S.A.

**Galvanized Metal, Metal & Alumina**  
on new galvanized metal must be removed before



Revised 12/2010

it is painted. Remove oil film with a detergent and